



Digital Probe Thermometer

Nothing else measures up!



Prospect House
George Cayley Drive
Clifton Moor
York
England
YO30 4XE

Tel: +44 (0) 1904 692723
Fax: +44 (0) 1904 690385

E-Mail: sales@yorksurvey.co.uk



Code: 32010

Operating Instructions

Digital Probe Thermometer

Function:

ON/OFF, H/T Function

One hour auto shut off function

Specification:

- Measurement range: $-50^{\circ}\text{C} \sim +150^{\circ}\text{C}$ ($-58^{\circ}\text{F} \sim +302^{\circ}\text{F}$)
- Accuracy: $\pm 1^{\circ}\text{C}$ in the range of $-30^{\circ}\text{C} \sim 150^{\circ}\text{C}$
- Ambient temperature for plastic casing: $-10^{\circ}\text{C} \sim +50^{\circ}\text{C}$ ($+14^{\circ}\text{F} \sim 122^{\circ}\text{F}$)

Battery: 1x 1.5V LR44 size or equivalent.

Installation:

- Unpack the thermometer with care.
- Open the battery door. Install one LR44 size battery into the battery compartment. Close the battery door.
- Slide off plastic sleeve - thermometer is now ready for use.
- Replace with new battery when the low battery indicator appears on screen.

Operation:

Press the "HOLD/TEST" button to "TEST" mode for temperature measurement or "HOLD" mode to retain reading for recording. The word "HOLD" will flash on the display to indicate the holding position.

Precautions:

- To obtain the best results, the probe tip should be immersed at least 10mm into the tested substance.
- Remove the battery from the battery compartment if the thermometer will not be used for a long time or during storage.
- The thermometer cannot be used or put inside any oven or microwave.

Battery Changing

